

Direct Level Calculation

Direct level

Input base point Elevation → B.M 1 10.000
Delete data ←

Route

21-Jul-08

Point	Name	B.S	F.S	I.H	Hight	Correct Elevation	Name	Point
1	B.M 1	1.336	1.297	11.336	10.000	10.000	B.M 1	1
2			1.350		10.039	10.039		2
3			1.203		9.986	9.986		3
4			1.323		10.133	10.133		4
5			1.231		10.013	10.013		5
6					10.105	10.105		6

Input BS Data

Input FS datum